

## Hand Switch for Hold-Open Systems

German fire protection regulations state that a switch with an appropriate inscription is obligatory for hold-open systems on fire protection doors.

The Dictator hand switch meets these demands. The fire-protection door is released by pressing the hand switch.

The hand switch is also available for flush mounting.

In hold-open systems with Dictator RM 3000+ smoke or WM 3000+ heat detectors and Dictator electromagnets, connect the hand switch to the first smoke or heat detector.

The hand switch should be mounted beside the door in a clearly visible position when the door is open.




### Order Information

Hand switch for surface mounting	part no. 040005
Rocker red without print for hand switch no. 040005	part no. 040005WRN
Rocker white without print for hand switch no. 040005	part no. 040005WWN
Hand switch for flush mounting	part no. 040053

**Dimensions**

**Hand switch for surface mounting**



**Hand switch for flush mounting**

