

Global Emergency-Open



To establish the global emergency-open function (when pressing the emergency-open switch on one door all doors of the interlock system are released) you have to retrofit the pluggable additional relay, part no. 710953. It is simply plugged in the provided socket (see below!). Besides that you have to remove on all control boards of the central controller RJ the jumper JP1 (respectively plug in on one pin only).

